



## CAMBIAR EL NOMBRE Y CLAVE DEL WIFI MARCA NCLINK


Debemos tener la computadora conectada por WIFI o por cable o también desde u celular o Tablet podes hacerlo. Debemos abrir cualquier navegador de internet “Internet Explorer, Google Chrome o Firefox” y en la barra de dirección escribimos la siguiente dirección **192.168.0.1**



Te pedirá contraseña, entonces pones **admin**



Luego te aparecerá la página de configuración del router, y entramos en “WLAN Settings” y allí podemos poner el nombre y la contraseña que deseemos.



Una vez que ponemos el nombre y la contraseña, debemos apretaren el botón

Save

Si deseamos Ocultar Red WIFI para que a nadie le aparezca, debemos tildar en "Disable" y luego apretar en save, como se muestra en la imagen de abajo:

The screenshot shows the 'Advance Settings' page for WLAN. The 'Broadcast(SSID)' option is set to 'Disable', which is circled in red. The 'Save' button is also visible.

Wireless  Enable

Network Mode 11b/g/n mixed mode

Broadcast(SSID)  Enable  Disable

BSSID 98:F9:C7:E7:71:4C

Channel AutoSelect Current Channel: 11

Channel BandWidth  20  20/40

Extension Channel Auto

Save Cancel

Si queremos ver los conectados que hay debemos entrar en Lan Setting y luego en DHCP List&Binding y allí aparecen los conectados.

The screenshot shows the 'DHCP List&Binding' page. The 'LAN Settings' and 'DHCP List & Binding' menu items are circled in red. A table lists connected devices with columns for Host Name, IP Address, MAC Address, and Lease Time. A red house icon is at the bottom.

IP Address 192.168.0. [ ]

MAC Address [ ] : [ ] : [ ] : [ ] : [ ] : [ ]

Add

NO.	IP Address	MAC Address	IP-MAC bind	Delete

Refresh

Host Name	IP Address	MAC Address	Lease Time
android-2cb911aa97b62b29	192.168.0.109	7C:1C:68:FC:99:26	23:58:16
	192.168.0.116	8C:9F:3B:A6:96:C0	23:25:13

Save Cancel