

CAMBIAR EL NOMBRE Y CLAVE DEL WIFI DE FIBRA OPTICA

Debemos tener la computadora o celular conectado por WIFI o por cable al router y entonces debemos abrir cualquier navegador de internet "Internet Explorer, Google Chrome o Firefox" y en la barra de dirección escribimos la dirección 192.168.30.2 y le damos a la tecla Enter

WEB Login

Username: admin
Password: admin18
Verification code: pg623
Login

Ingresamos el codigo que nos aparece y luego click en Login

Una vez que ingresamos al router en la siguiente imagen le muestra como cambiar el nombre de la red

Site Contents:
Status
LAN
1. WLAN
2. Basic Settings
Advanced Settings
Security
Access Control
Status
WAN
Services
Advance
Diagnostics
Admin
Statistics

WLAN Basic Settings

This page is used to configure the parameters for WLAN clients which may connect to this Access Point. Here you may change wireless encryption settings as well as wireless network parameters.

☐ Disable WLAN Interface

Band: 2.4 GHz (B+G+N)
Mode: AP Multiple AP
SSID: 3 NombreWifi
Channel Width: 20MHz
Control Sideband: Upper
Channel Number: Auto
Radio Power (%): 100%
Associated Clients: Show Active WLAN Clients

4 Apply Changes

Ahora en la siguiente imagen le muestra cómo cambiar la Clave de su Wifi

Site Contents:
Status
LAN
1. WLAN
Basic Settings
Advanced Settings
2. Security
Access Control
Status
WAN
Services
Advance
Diagnostics
Admin
Statistics

WLAN Security Settings

This page allows you to setup the WLAN security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

SSID Type: Root AP - RAMIRO

Encryption: WPA2 Mixed

Authentication Mode: ☐ Enterprise (RADIUS) ☒ Personal (Pre-Shared Key)

WPA Cipher Suite: ☒ TKIP ☒ AES
WPA2 Cipher Suite: ☒ TKIP ☒ AES

Group Key Update Timer: 86400

Pre-Shared Key Format: Passphrase

Pre-Shared Key: 3 clavedewifi

Show Key: ☒

4 Apply Changes